



- |    |  |  |
|----|--|--|
| 1  | BATT Switch                                | Battery power supply (Master Switch)   |
|    | ALT 2 Switch                               | ALT 2 power supply (Master Switch)   |
| 2  | Start Button                               | Engage starter motor   |
| 3  | Ignition Key                               | Disconnect Ignition  |
| 4  | PFD  | Garmin G500 TX -Primary Flight Display   |
| 5  | Audio Panel                                | Garmin GMA345 - Distribute audio to crew   |
| 6  | GPS  | Garmin GTN 650 - GPS with integrated Radio & Transponder   |
| 7  | COM2                                       | Garmin GNC 255A - 2nd COM / NAV radio  |
| 8  | EMS  | JPI EDM900 Engine Monitoring System (EMS)  |
| 9  | Warning lights                             | Alternator and engine warning lights   |
| 10 | Backup Instrument                          | Backup Flight Instrument with ASI, AI, Alt   |
| 11 | Equipment switches<br>(from left to right) | <ul style="list-style-type: none"> <li>- TCU: Freeze the turbo waste gate position when off</li> <li>- AVI 1: Audio Panel and GPS</li> <li>- AVI 2: COM2 and Backup Instrument</li> <li>- Instrument lights</li> <li>- Anti-collision lights</li> <li>- Navigation lights</li> <li>- Landing light</li> <li>- Taxi light</li> <li>- Aux fuel pump</li> </ul> |
| 12 | Panel dimmer                               |  |
| 13 | Flap pos. indicator (left)                 | UP, T/O, APP, LD   |
|    | Flap selector (right)                      | from top to bottom: UP, T/O, APP, LD   |
| 14 | Choke                                      |  |
| 15 | Carburettor heater                         |  |
| 16 | Circuit breaker board                      |  |
| 17 | Cabin heat system                          |  |
| 18 | Aux 12V Plug                               |  |